

### Flashing against Exterior Walls


DKRR'HFNSURYGHVDFRORUPDWFKHGUODKORUWDOODWRBWRSRVKHG'HNWHP,W  
PHDMHDDWDFKHGDKKH77RU7UPHDG6FUHZ  
SDSSOMDODW WRWKHEDFNDGERWWRPCHRIWKHSDODKDEHIRUHWDOODWRQ  
7KLODKDGGWRWRBWDHRIWDGDUGOHGJHUIODKQWCHDOWRWDOOWKH  
IODKDEHKGWKHGOLSRFOH



## Installation of Profile Plugs

Wahoo Decks provides neoprene profile plugs for the void created on the bottom side of the decking where it crosses the support header on the drainage side. The plugs are designed to block air, driving rain, debris, insects, etc. from being able to get under the decking at this void.

The plugs come in labeled bags for easy identification. Each deck board receives two plugs, and each profile is a different size. Each plug is designed to be slightly larger than the profile it is intended for and must be compressed into place. Be sure to install after the decking is fastened down to the framing and before the profile trim.



## Stairs

Stairs can be accomplished by using a Main Board and Finish Board to create a maximum 11 1/2" tread.



\*If using our Wahoo Aluminum Rail Kits, refer to the drawing below for attaching through AridDek. Always add additional timber blocking to the framing below each Post Mount. Each 3/8" lag screw must fasten through the deck board and into timber framing below. Mark and pre-drill a 3/8" hole in each of mounting holes through the AridDek and use the supplied 3/8" wood lag screws to attach the pedestal mount. \*Refer to the "Wahoo Rail Install Guide" for complete rail installation details.



Please contact our customer service team at (877) 270-9387 with any questions. We appreciate your business and we look forward to your feedback!

ENJOY YOUR NEW DECK!

